



Schraubdeckelöffner

Jar opener - Apribarattoli



Öffnet alle Schraubdeckel mit Durchmesser von 25 mm bis 102 mm.

Ouvre tous les bocaux avec un diamètre de 25 mm à 102 mm.

Opens all jars with diameter of 25 mm to 102 mm.

Apri tutti i barattoli con un diametro di 25 mm a 102 mm.

Abre todos los botaes con tapas de un diámetro de 25 mm a 102 mm.

HOUSEWARES GERMANY
HWG Products GmbH
Rudolf-Diesel-Straße 24
78224 Singen (Hohentwiel)

Phone: +49 (0) 7731 / 79611-0
Fax: +49 (0) 7731 / 79611-99
info@housewares-germany.de
www.housewares-germany.de



Einfaches Öffnen, ohne Kraftaufwand.

Ouverture facile et sans effort.

Easy opening without effort.

Apertura facile e senza sforzo.

Apertura fácil y sin esfuerzo.



Knopf drücken und Stiel herausziehen.

Appuyer sur le bouton et tirer la tige.

Press the button and pull the rod.

Premere sul pulsante e tirare l'impugnatura.

Apretar el botón y sacar la varilla.



Anpassen

Ajuster

Adjust

Adeguare

Ajustar



Drehen und öffnen

Tourner et ouvrir

Turn and open

Girare e aprire

Girar y abrir